

Invisible Radiant Cream SPF50

1704-2.23



+ Day care





Phase	Name	INCI	Supplier	%
A1	DEMINERALIZED WATER	WATER	_	23.17
	CARBOPOL® AQUA SF-1 OS POLYMER	ACRYLATES COPOLYMER	Lubrizol	3.00
A2	SATIAXANE™ CX91	XANTHAN GUM	Cargill	0.30
	BUTYLENE GLYCOL	BUTYLENE GLYCOL	_	3.00
A3	AMPHISOL® K	POTASSIUM CETYL PHOSPHATE	DSM	0.50
	DEMINERALIZED WATER	WATER	_	7.00
A4	SODIUM HYDROXIDE (10 % SOL.)	WATER, SODIUM HYDROXIDE	_	0.50
A5	E.D.T.A. DISODIUM SALT	DISODIUM EDTA	_	0.10
A6	PARSOL® HS	PHENYLBENZIMIDAZOLE SULFONIC ACID	DSM	3.00
	DEMINERALIZED WATER	WATER	_	3.00
	SODIUM HYDROXIDE (10 % SOL.)	WATER, SODIUM HYDROXIDE	-	3.75
В	EMULIUM® MELLIFERA MB	POLYGLYCERYL-6 DISTEARATE, JOJOBA ESTERS, POLYGLYCERYL-3 BEESWAX, CETYL ALCOHOL	Gattefossé	4.00
	C12-15 ALKYL BENZOATE	C12-15 ALKYL BENZOATE	-	8.00
	COCOATE™ BG	BUTYLENE GLYCOL COCOATE	Gattefossé	3.00
	TINOGARD® TL	BENZOTRIAZOLYL DODECYL P-CRESOL	BASF	0.50
	TINOSORB® S	BIS-ETHYLHEXYLOXYPHENOL METHOXYPHENYL TRIAZINE	BASF	2.50
	PARSOL® 1789	BUTYL METHOXYDIBENZOYLMETHANE	DSM	3.00
	UVINUL® A PLUS	DIETHYLAMINO HYDROXYBENZOYL HEXYL BENZOATE	BASF	2.00
	PARSOL® EHS	ETHYLHEXYL SALICYLATE	DSM	5.00
	SOLAVEIL™ ST-100	C12-15 ALKYL BENZOATE, TITANIUM DIOXIDE, POLYGLYCERYL-3 POLYRICINOLEATE, SILICA, STEARIC ACID, AMINOPROPYL TRIETHOXYSILANE	Croda	9.00
С	SODIUM HYDROXIDE (10 % SOL.)	WATER, SODIUM HYDROXIDE	_	0.90
D	CARESIL™ CES-1104	WATER, DIMETHICONE, GLYCERIN, DIMETHICONE/VINYL DIMETHICONE CROSSPOLYMER, PENTYLENE GLYCOL, PHENOXYETHANOL, AMODIMETHICONE, CARBOMER, SODIUM HYDROXIDE, DISODIUM EDTA	Nusil	5.00
Е	PRESERVATIVE	PRESERVATIVE	_	0.70
	GATULINE® RADIANCE	PROPANEDIOL, EVODIA RUTAECARPA FRUIT EXTRACT	Gattefossé	2.00
	GATULINE® RC BIO	WATER, FAGUS SYLVATICA BUD EXTRACT	Gattefossé	2.00
	MIRAGE BRIGHT RED	CALCIUM SODIUM BOROSILICATE, TITANIUM DIOXIDE, TIN OXIDE	Eckart	0.80
	UNICERT YELLOW 08005-J (1.0% SOL.)	WATER, YELLOW 5	_	0.08
	UNICERT RED 07004 J (1.0% SOL.)	WATER, RED 4		0.08
F	ORGASOL® CARESSE	POLYAMIDE-5	Arkema	3.50
	PERFUME SNOWFLAKE	PARFUM	Firmenich	0.20
G	SODIUM HYDROXIDE (10 % SOL.)	WATER, SODIUM HYDROXIDE	_	0.42

Operating instructions

- Prepare A1. Then premix A2, add to A1 and mix until the Xanthan Gum swells. Then heat to $75\,^{\circ}\text{C}.$
- Prepare A3 and heat to 75°C then add to batch.
- Add A4 to batch under mixing, then add A5 and mix until complete solubilization of EDTA.
- Prepare A6 and mix until complete solubilization of Parsol $^{\! \circ}$ HS and add to batch.
- Prepare B and heat to $80\,^{\circ}\text{C}$ under mixing until complete solubilization of UV filters.

100.00

- Introduce slowly B into A under mixing and homogenize for 15 minutes at 1500 $\ensuremath{\text{rpm}}$.
- Cool to $50\,^{\circ}\text{C}$ under moderate mixing (about 800 rpm), then add C and D under mixing and homogenize at 1500 rpm for 2 minutes.
- Complete cooling to 30°C under moderate mixing and add E and F.
- Adjust the final pH above 7.2 with phase G.



Invisible Radiant Cream SPF50 1704-2.23

3 (

- + Day care
- + Light texture
- + Natural glow

Description

Skin is radiant and moisturized with this highly protective suncream and the help of Gatuline® RC Bio and Gatuline® Radiance, two clinically evaluated actives. The emulsifier, Emulium® Mellifera MB, provides ideal lightness upon application, despite the high UV protection, and is perfect for sensitive skin with a formulation free from suspected endocrinian disruptors.

Specifications

- + Aspect:
 Very light orange glossy cream
- $+ pH = 7.3 \pm 0.3$
- + Viscosity Brookfield RV (spindle B, speed 5): approx. 45 000 mPa.s after 24h
- + SPF in vivo (ISO 24444): 53.6 (4 subjects)
 UVA in vitro (ISO 24442): 29.7
 Photostability = 92%
 Critical wavelength (ISO 24 443) = 380 nm
 UVA / PA++++

Ingredients

- **Emulium® Mellifera MB** at 4% creates a rich and comfortable cream with an ideal lightness for a sunscreen.
- Parsol® 1789 and Uvinul® A plus are UVA filters and Parsol® EHS is a UVB filter. Tinosorb® S and Solaveil™ ST-100 are broadspectrum UV filters.
- Parsol® HS is a hydrosoluble UVB filter.
- Amphisol® K is a co-emulsifier that improves the stability in presence of sun filters.
- Cocoate™ BG and C12-15 Alkyl Benzoate are used to ensure optimal dispersion of the sun filters.
- Caresil™ CES-1104 and Orgasol® Caresse are feeling agents that improve the softness upon application.
- **Gatuline® Radiance** enhances all aspects of a radiant complexion, including skin color, brightness and luminosity.
- Gatuline® RC Bio increases skin hydration and minimizes fine lines for a healthier and younger look.

This formula is presented in good faith, however, no warranty as to the accuracy or completeness of results, or fitness for a particular use is given, nor is freedom from the infringement of any intellectual/industrial property rights to be inferred. It is provided "as is" for your consideration, investigation and verification. To the extent permissible by applicable law, Gattefossé shall in no way be liable for any reliance upon information or materials provided.